

TX500/136 Menu v1.05a

PWR	Short pulse	Power ON					
	Long pulse	Power OFF					
	Long start pulse	[Service mode] Config	Short pulse	Set Ref Osc Freq	UP / DOWN	20000000 Hz TX136 60000000 Hz TX500	
				Supply Calibration	UP / DOWN	100 to 200	
				Beep lengh	UP / DOWN	0 to 100 ms	
				Forward PWR Cal	UP / DOWN	0 to 100	
				Current Cal	UP / DOWN	3000 to 5000	
				CW break period	UP / DOWN	5 to 10	
				Factory defaults	OPER	Long pulse	Quit
		OPER	Short pulse	Save and quit			

Display	Short pulse			Power				
				SWR				
				Voltage				
				Current				
	Long pulse	Config	Short pulse	Mode	Up / Down	CW	CW only	
						QRSS		
						DFCW		
				Pre Amplifier	Up / Down	OFF		
						10 dB		
						20 dB		
				Converter	UP / DOWN	OFF		
						ON		
				CW Keyer	UP / DOWN	Dot priority		
						Iambic A		
						Iambic B		
						Straight		
						Beacon		
				CW Sidetone	UP / DOWN	Off to 2000 Hz		
				SWR Protection	UP / DOWN	1 to 99		
					RF PWR	PWR MIN		
						PWR LOW		
						PWR HI		
						PWR MAX		
				Display Brightness	UP / DOWN	0 to 1100		
				Display Contrast	UP / DOWN	0 to 3500		
				Serial Protocol	UP / DOWN	TX136/500		
						Terminal		
				Serial Speed	UP / DOWN	1200 to 115200		
				TX Control	UP / DOWN	MOX		
						Auto		
				Spare I/O signal	UP / DOWN	OFF		
						ON		
			Long pulse	Quit				

CW UP / CW DOWN	Short pulse	CW 1 to 50 wpm			Dot time
		QRSS 1 to 120 s			Dot time
		DFCW 1 to 120 s	Short pulse	PWR	Dot time
		DFCW 0.1 to 5 Hz			Dash shift

OPER	Short pulse	STBY		
		OPER	Long pulse	Start beacon
		TUNE		Stop beacon

RF PWR	Short pulse	PWR MIN		
		PWR LOW		
		PWR HI		
		PWR MAX		

FREQ+ / FREQ-	Short pulse	Step 1 Hz	TX136 : 135.7 to 137.8 KHz		
	Short pulse	RF PWR	Long pulse	Step 100 Hz	TX500 : 472 to 479 KHz